



Scaling the 4-20 mA Input

Enter the *Input* menu to scale the meter to display the 4-20 mA input. The input can accept any signal from 4 to 20 mA.



Setting the Display Features

The meter's display functions may be programmed using the *Display* menu. This menu consists of the following submenus: *Units, Decimal Point, Comma, Bargraph, Top, and Bottom.*



Changing the Engineering Units


It is possible to change the engineering units within the selected unit class without the need to re-scale the meter. (*Feet and Inches model must be in dual-scale mode to enable.*) When selecting a new unit from within the *Display* menu (e.g. changing from gallons (GAL) to liters (L)), the meter will automatically convert the display values to display the new unit. Enter the *Units* menu, select a new unit of measure from the list of predefined units, and press the *Enter* button. If entering a custom unit (CUSTOM), the input must be scaled using the custom unit.

Feet & Inches Display

The *Units* menu is used to change how fractional inches are represented. The options are automatically reducing, 1/16, 1/8, 1/4, 1/2 of an inch, or no fractions. The default setting (FT-IN/#) automatically reduces the fraction to the lowest denominator.


Programming the Bargraph

The DPM-400 comes equipped with a bargraph display for applications where a visual representation of the process variable's percentage of full scale is desirable. This feature can be enabled or disabled using the Bargraph menu (BARGRAPH). The value displayed on the bargraph can be the percentage of full scale (PV PCT) or the percentage of a user-programmable range (PV%). If the meter is in dual-scale mode, the bargraph can be assigned to display either PV1 or PV2 using this menu.



Programming the Outputs

Depending on the model purchased, the meter may be available with two open collector outputs, two solid state relays, and one 4-20 mA output. The Output menu will only show options for the available outputs.



Open Collector Outputs

The meter is equipped with two NPN open collector outputs as a standard feature that may be set up for pulse outputs, alarms, timed pulses, or disabled.

Pulse outputs can be set to transmit the PV value (PV1 or PV2 if meter is in dual-scale mode). Output 2 may be used to generate a quadrature output based on the other open collector output. An output test mode is also selectable to generate pulses at a constant programmable frequency.


Alarms are available based on the PV value or the digital input. The alarm status will show on the display even if the output is not wired.

A timer output (TIMER) turns the open collector on and off at the specified time intervals. The timer can be set as single-shot or continuous timer.

The stopwatch output (STPWATCH) allows the open collector to be manually activated by starting the stopwatch. The stopwatch count can be displayed on the top or bottom display.

The output may be disabled by selecting *DISABLE*.

The Open Collector Outputs are programmed in the following manner:



To program the meter for a PULSE Output, refer to the instruction manual found at predig.com.

Solid-State Relay Outputs


The meter can be optionally equipped with two solid-state relays that may be set up for alarms, timer, stopwatch, or pump control. Alternatively, they may be disabled.

Alarms are available based on the PV value or the digital input. The alarm status will show on the display even if the output is not wired. Pump control allows the relay to turn on and off a pump at specified on and off points. This can be done using only one of the relays to control one pump (ON-OFF) or using both relays in tandem to alternate between two pumps (ALTERN). A timer output (TIMER) turns the relay on and off at the specified time intervals. The timer can be set as single-shot or continuous timer. The stopwatch output (STPWATCH) allows the relay to be manually activated by starting the stopwatch. The stopwatch count can be displayed on the top or bottom display.

The output may be disabled by selecting *DISABLE*.

CAUTION


- During setup, the relays do not follow the input and they will remain in the state found prior to entering the *Relay* menu.



Isolated 4-20 mA Output


The 4-20 mA menu is used to scale the isolated 4-20 mA output based on display values. This menu is not present on models without a 4-20 mA output option.

The 4-20 mA analog output can be scaled to provide a 4-20 mA signal for any PV display range or to simply retransmit the 4-20 mA input. The output may be disabled (*DISABLE*), and will only output the minimum signal. Overrange and underrange values determine what mA signal the meter will output if the mA input is underrange (<3.5 mA) or overrange (>20.5 mA). This value may be set to 1 mA, 3.5 mA, 3.8 mA, 20.5 mA, 20.8 mA, 23 mA, or disabled. No equipment is needed to scale the analog output; simply program two display values and corresponding mA output signals.



Enabling Password Protection

The *Password* menu is used for programming security to prevent unauthorized changes to the programmed parameter settings. To set a password, enter the *Password* menu and program a five-digit password.




Advanced Features Menu

For features and capabilities not commonly used during setup, see the complete instruction manual found at www.predig.com for details on the *Advanced Features* menu.

Reset Meter to Factory Defaults

When the parameters have been changed in a way that is difficult to determine what's happening, it might be better to start the setup process from the factory defaults. This can be accomplished using MeterView XL software or with the front panel buttons.

- Press the *Menu* button to enter *Programming Mode*.
- Press the *Right-Arrow* button twice and press *Enter* to access the *Advanced* menu.
- Press the *Up-Arrow* button and press *Enter* to access the *System* menu.
- Press the *Right-Arrow* button and press *Enter* to access the *Default* menu.
- Press *Enter* twice in quick succession. The meter will load default settings and restart.



Limited Warranty

BinMaster warrants this product against defects in material or workmanship for the specified period as detailed in the "Specifications" section of the complete manual from the date of shipment from the factory. BinMaster's liability under this limited warranty shall not exceed the purchase value, repair, or replacement of the defective unit. See Warranty Information and Terms & Conditions on www.binmaster.com for complete details.