

CNCR-Compact Non-Contact Radar Level Sensor

For assistance call 1-800-278-4241 or 402-434-9102

Scan this QR code and then download with the App Store or Google Play version of the Wireless Device Configurator app suited to your phone.




<https://apps.apple.com/us/app/binmaster-sensor-app/id6478102938>



<https://play.google.com/store/apps/details?id=com.binmaster.sensorapp>


When setting up each sensor, you need to enter the sensor's Bluetooth Access Code to activate it.

To enable Bluetooth software enter company ID code:



BMYQXZ

Where to find the Access Code on the unit:



https://www.binmaster.com/documents.htm?doc_Type=253&doc_category=271&doc_mod-els=294&product_list_mode=list

Download the manual:

Scan this QR code to visit the CNCR Manual web page. Then, select the manual appropriate to the CNCR sensor you are installing. Scroll to bottom and click "Downloads".